



Window Vent Shades Stainless

Installation Instructions



Notes:

1. Note: please read through all instructions prior to removing or installing any part. If you do not feel comfortable with the instructions or in your ability to install or modify your vehicle, please take to a reputable mechanic to have them perform the installation. BJ's Off-Road can not and will not determine your ability to install this kit, and the extent of our warranty and liability only cover the components of this kit, and do not cover improper installation, abuse, neglect, labor rates, etc. Contact us with any questions prior to installation.



Stainless steel window vent shades. Keep the rain out of your rig and still be able to open your windows a bit. In addition, these add a really refined look to your rig.

Step 1: Open windows before installing vent shades.

Step 2: Position vent shade slightly below the window opening and insert the flat flange in between the division bar and steel bead of glass run. If the opening is not wide enough to insert the flange, separate it slightly with a putty knife or other sharp-edged tool.

Step 3: Insert curled flange at the opposite end, between the window frame and the glass run.

Step 4: Slide the vent shade upward until contact is made with the upper window frame. Then, starting at the corners and working toward the center, apply upward pressure to the upper curled flange until it seats between the glass run and the window frame. Using a blunt edged instrument to pry the outer lid of the glass run away from the vent shade will ease seating the vent shade flange and will prevent buckling of the glass run.

Step 5: Using the holes in the vent shade as a guide, drill 5/64" diameter holes into the window frames.

Step 6: Install #4 x 1/4" self-tapping screws, using a magnetized screwdriver. NOTE: Extreme care must be taken when drilling holes. Drill must be held steady to assure proper hole size. Excessive pressure will result in broken drills.

- CAUTION - Before driving, ensure that the vent visor is properly secured to vehicle.
- Do not use automatic "brush-style" car washes.
- Do not use cleaning solvents of any kind.
- Periodically check all components for tightness.
- Wash only with mild soap & dry with a clean cloth