



## Interior Hand Grabs Instructions



### Notes:

1. Note: please read through all instructions prior to removing or installing any part. If you do not feel comfortable with the instructions or in your ability to install or modify your vehicle, please take to a reputable mechanic to have them perform the installation. BJ's Off-Road can not and will not determine your ability to install this kit, and the extent of our warranty and liability only cover the components of this kit, and do not cover improper installation, abuse, neglect, labor rates, etc. Contact us with any questions prior to installation.



#### Tools Required:

- 1/16" and 1/8" drill bits
- 3/8" socket
- 1/4" drive ratchet
- Drill
- Center Punch

#### **Front Grab Handle Instructions**

1. Position the hand grab on the A pillar (front pillar at the windshield).
2. Mark the pair of holes with a sharpie (this is for the center punch). Remove the hand grab and set aside. Using a hammer, carefully center punch the mark (be VERY careful not to hit / damage the windshield).
3. Drill a 1/16" pilot hole in each of the marked / punched locations. **PROCEED WITH CAUTION!!!** The drill bit may bottom out from the thickness of steel in this area, causing the bit to break.
4. Next, redrill each of the holes from the previous step using the 1/8" drill bit.
5. Place the hand grab in alignment with the holes and tighten down the bolts (do not overtighten / strip the holes).

#### **Rear Grab Handle Instructions**

1. Position the hand grab on the B pillar (pillar between the front and middle door), with the top piece 2" above the seat belt bolt.
2. Mark the pair of holes with a sharpie (this is for the center punch). Remove the hand grab and set aside. Using a hammer, carefully center punch the mark (be VERY careful not to hit / damage nearby items).
3. Drill a 1/8" hole in each of the marked / punched locations.
4. Mount the lower mount under and behind the seat belt bolt
5. Place the hand grab in alignment with the holes and tighten down the bolts (do not overtighten / strip the holes).